

PRO SERIES 4-PISTON REAR BRAKE KIT INSTRUCTIONS

KIT #
B1721WC
B1721WCM

APPLICATIONS
94-04 Mustang OEM Ends using
A1094, A1095, A1096, A1097
Strange Eliminator Kits


Before you begin installation

Brake rotors are shipped with an oil film on the surface to prevent rust and must be cleaned before installation.
Brake fittings do not come pre-installed, it will need a layer of Teflon sealer applied to the thread (Figure#1 for torque specs)
Read these instructions thoroughly and save for future reference.
If after reading these installation instructions, you have any questions or comments, please do not hesitate to call us.

KIT CONTENTS


ITEM#	PART#	QTY	DESCRIPTION
1a	B2792	1	RH rotor
1b	B2793	1	LH rotor
2a	B1721AL	1	94-04 Mustang LH caliper mount
2b	B1721AR	1	94-04 Mustang RH caliper mount
3	B1301E	4	Press Nut
4	B1301H	16	0.025 Thick shim
5a	B5002	1	Caliper RH
5b	B5004	1	Caliper LH
6	B5010	4	Soft metallic 4-piston brake pad (B1721WC)
7	B5020	4	Hard metallic 4-piston brake pad (B1721WCM)
8	P2316	2	-1/8 NPT x -3AN fitting
9	P2316C	2	Plastic Cap
10	B1301J	4	Washer 3/8 ID
11	B5000Y	4	3/8-24 x 1.125" HHCS
12	A1100F	2	Seal
13	A1092E	2	Gasket

FIGURE # 1: B1721WC Exploded view



Installation instructions

FIGURE # 2:



1. Remove wheel and tire, brake caliper and rotor.
2. Remove axle from the housing.
3. Refer to A1094, A1095, A1096, A1097 for C-clip eliminator kit assembly instructions.
4. Slide the caliper mount (2) with seal (12) over the safety hub studs with the press nut side facing outboard.
5. Place the gasket (13) between the housing end and inboard side of the caliper mount, applying RTV to both sides of the gasket. (See Figure #4)
6. Secure the the four safety hub studs with nuts and torque to 35 ft-lbs.
7. Install the factory ABS sensor and retaining bolt if applicable.
8. Slide the rotor (1) over the wheel studs and axle flange, ensuring that the rotor sits flat on the face of the axle flange.
Note: Slotted rotors mount with the arrow pointing in the direction of normal rotation (See Figure #2).
 - Please read B1850 instructions for complete caliper instructions.
9. Attach caliper (5) with the arrow facing in the direction of normal rotor rotation using 3/8"-24 caliper bolts (11) with red loctite and 1/16" thick flat washers (10). Use 0.025" thick caliper shims (4) to center the caliper over the rotor, making sure pads contact the rotor evenly.
10. The caliper bolt (11) should be fully engaged into the press nut. If the bolt is over engaged, use any remaining shims under the head of the bolt to prevent it from running into the rotor. Torque the caliper mounting bolts (11) to 35 ft-lbs.
11. Connect the brake lines to the calipers. Calipers are tapped to 1/8"-27 NPT and supplied with -3AN fittings. Use proper adapters to connect them to existing lines or use new -3AN braided steel line (teflon lined). Bleed the calipers with DOT 4 or DOT 5.1 **ONLY** brake fluid.

12. A proper break in procedure is required to avoid brake fade and uneven rotor deposits from the pads. It consists of 8-10 brake applications increasing in harshness while allowing the brakes to cool slightly in between; do not keep the brakes applied between stops. After the last stop the brakes should be allowed to cool completely.

Note: After the initial installation of this kit, ensure that there is adequate clearance between all braking and chassis components by moving the suspension all the way up and down throughout its travel. Additionally, make sure that the brake lines are not interfering with the wheel travel, or subject to binding or kinking. Operate the vehicle in a cautious manner until you determine that the brakes are functioning properly. Routinely check and re-torque all bolts.

FIGURE # 3: Axle B-dimension





FIGURE # 4: Caliper mount RTV



WARNING – RACING IS HAZARDOUS · STRANGE BRAKES ARE FOR LEGAL DRAG RACING ONLY

Disclaimer of Warranty – Purchasers using Strange Engineering racing components and equipment any and all inventory services, purchasers acknowledge that due to differing conditions and circumstances under which all equipment and parts are installed and used, purchasers are not relying on Strange Engineering Co. skill or judgment to select or furnish the proper part or equipment. Purchasers expressly affirm they are relying upon their own skill or judgment to select and purchase Suitable goods.

Strange Engineering Co. makes no warranties whatsoever, expressed or implied, oral or written, to purchasers. There is no warranty of merchantability made to purchasers. Strange Engineering Co., further excludes any implied warranty of fitness with respect to racing and equipment, any and all inventory and service.